


Function diagram
Float chamber ventilation and fuel evaporation control system

- 1 Carburetor
- 33 Vacuum valve for air injection
- 35 Check valve
- 37 Electric switchover valve for float chamber ventilation
- 38 Draw-off valve
- 41 Decel diverter valve (air injection)
- 284 Fuel return valve (vacuum-actuated)
- b Negative tank vent connection

Line colors
 bl = blue
 gn = green
 gn/vi = green/purple
 sw = black



Test conditions:

All electric fuses in order. Engine at operating temperature. Sealing at vacuum end of decel diverter valve (41) and switchover valve (33), as well as their function in order.

